

ER7-700


7D Ž JY --

IP


C



/OPERATING SPACE



/BASE MOUNTING SIZE



/END FLANGE MOUNTING SIZE

