


ESR10-800Z42


ESR - Z
kg mm




/SPECIFICATION

	ESR - Z
	mm
	kg
	kg
	mm/sec
	mm/sec
	°/sec
	± °
	± °
	mm
	± °
	± . mm
	± . mm
	± . °
	. s
J	. kg m


/OPERATING SPACE



/BASE MOUNTING SIZE



/END FLANGE MOUNTING SIZE



m/